


DS 10-AATXATS-02

Dissolution Drawing



NO.	Component Name	Amount	Component NO.
1	HexagonScrew	16	PC000003SW
2	Oring	2	PB000002
3	HexagonScrew	8	PC000002SW
4	DownBallSeat	2	PA000010
5	Oring	4	PB000084
6	UpBallSeat	2	PA000022
7	UpBallCover	2	PA000311
8	DownBallCover	2	PA000312
9	Ball	4	PB000043
10	Teflon Pad	2	PB000415
11	HousingOfPump	2	PA0000410
12	SteelHexagonScrew	2	PC000173
13	SteelWasher	2	PC000058
14	PadOfDiaphragm	2	PA000224
15	OutsideDiaphragm(PE)	2	PB000033N
-	OutsideDiaphragm(Teflon)	2	PB000028N
16	InsideDiaphragm	2	PD000085
-	Diaphragm	2	PD000086
17	PadOfDiaphragm	2	PA000225
18	Oring	2	PD000010
19	ShaftCover	2	PB000176
20	Oring	2	PD000009
21	Oring	2	PD000007
22	ShaftOfDiaphragm	1	PA000084
23	BodyOfThimbleValve	1	PA000189
24	Oring	1	PD000017
25	Oring	1	PD000006
26	Oring	1	PD000004
27	Oring	3	PB000088
28	Oring	3	PD000025
29	Oring	1	PD000002
30	Thimble	1	PA000201
31	ThimbleCap	1	PB000361
32	HexagonScrew	4	PC000101SW

NO.	Component Name	Amount	Component NO.
33	AbnormalOring	1	PD000138
34	AbnormalOring	1	PD000131
35	BodyOfSequential	1	PA000104N
36	PistonOfAirValve	1	PA000080
37	U-TypeOring	1	PDD00025
38	U-TypeOring	2	PDR00018
39	StartingCopperLatch	2	PA000112
40	CoverOfSequential	1	PB000064
41	CoverOfSequential	1	PB000065
42	Oring	2	PD000002
43	HousingOfSequential	2	PB000020
44	BodyOfCylinderBase	1	PA000097
45	HexagonScrew	4	PC000013SW
46	Pipe	2	PA000213N
47	HexagonScrew	8	PC000118SW
50	Silencer	1	PB005331
51	AirPressureRoomOfPump	2	PA0001950
52	HexagonBung	6	PC000416
53	SlitheryMassValve	1	PB000067N
54	IncludePly	1	PA000037
55	Oring	2	PD000024
56	Oring	1	PD000038
57	Oring	1	PD000018

*"Some model don't include this parts. [spraytools](http://www.spraytools.com)